

## Installation Procedure: Window Perf- 80/20, 70/30, 60/40

### Tools Needed:

Soap and water  
Lint free cloth or paper towels  
Level  
Soft Plastic Squeegee  
Utility Knife

### Install According To Instructions Only:

The supplier shall provide a complete copy of Murals Your Way's current installation instructions to the installer prior to receiving the Window Film. All installations must conform to the Murals Your Way current installation instructions in order for the Murals Your Way Love It Guarantee™ to apply. If the Window Film is installed in a manner other than that recommended by Murals Your Way, it is done at the sole risk of the installer and the Murals Your Way Love It Guarantee™ protections do not apply.

### Check Shipment for Accuracy:

All labels shall be checked for accuracy by the installer to ensure that the shipment is received as ordered. If any discrepancy is found, Murals Your Way should be contacted immediately. Check Product for Defects: If no defect is evident before installation, proceed with the installation. After each panel is installed, the material should be inspected. If any defect is evident at this time (or at any point of the installation) no further material should be applied and Murals Your Way should be contacted IMMEDIATELY. If there are any questions on the following instructions, contact your supplier before proceeding.

### Window Preparation:

- Glass surface must be clean. Use mild soap and water to clean the glass or 85% isopropyl alcohol, if desired, to remove any residue; do not use glass cleaners with solvents (e.g., Windex®). Allow it to evaporate completely before installing Window Perf.
- Surface must be completely dry. Use lint-free cloth or industrial paper towels to dry glass.
- Temperature of glass must be moderate —between approx. 40° F (5° C) and 90° F (32° C).
- In cold weather, apply film in late afternoon, after windows have warmed up. Applying Window Perf to glass that is too cold may adversely affect adhesion.
- In hot weather, apply Window Perf in the early morning, while glass is still cool. Applying the vinyl to glass that is too hot can cause the film to stretch during installation.

### Hanging Guidelines:

It's time to start hanging your Window Film.

## Step 1

Lift the upper edge of the liner away from the vinyl and fold back approximately 3-6 inches.

## Step 2

Carefully position the vinyl so that it is properly aligned on all sides. Be sure that the vinyl is straight and in the desired position and then press the upper corners in place using light pressure.

## Step 3

Working from the top of the graphic to the bottom, continue by peeling away more of the liner and applying light pressure to the vinyl, smoothing from the middle outward. Continue until the liner is completely removed and the window graphic is in place.

## Step 4

Using a utility knife, carefully trim away any unneeded portion of the graphic. To improve adhesion, leave a small gap between the vinyl and the window frame to avoid premature release from the corner and the edges of the vinyl. Never have the graphic overlap the edge of the window.

## Step 5

If you are installing more than one panel, follow steps 1 through 4 for each panel. Carefully align each panel in relation to the adjoining panel(s). If the panels must be seamed together, install the two pieces so that the edges of the vinyl butt up against each other. (DO NOT overlap the panels).

## Step 6

Make sure the graphic is securely in place. Squeegee the entire graphic from the center and work outward. Be sure to squeegee the edges firmly in place.

## Step 7

Step back and enjoy!

## Removal

Apply a 2" wide piece of permanent tape along one edge of the vinyl. Pull up the vinyl along that edge- once the whole edge has been lifted from the surface, pull the graphic along the tape line off the surface in a smooth, slow motion. The vinyl should peel off easily in strips or sections. In areas where the vinyl does not remove cleanly, spray the area liberally with a solvent-based glass cleaner (e.g., Windex). Let sit for a minute or two, then remove the film.